



**AX1164**



Fixation on the frame with original screws

Fixation sur le cadre avec vis d'origine

**Radiator guards Husqvarna 125WR 11**

- Liste de visserie :**
- 8\*NE01-01-001 ( tbhc 6\*16)
  - 6\*NE01-01-008 (Tbhc 6\*25)
  - 2\*NE01-04-003(Em6f)
  - 2\* NE01-01-009 (tbhc 6\*20)
  - 4\* PM03-02-018(Red Spacer 107 red)\* 4
  - 1\*pm01-04-080



Tbhc 6\*35 Em6f

Pm01-04-080

**Mounting:**

- A: Put down radiator covers, air deflectors and radiator screws
- B: Assemble **1,2,3** and 4
- C: Mount the group on the radiator
- D:Link both sides with PM1-04-080
- E: Put back air deflectors, radiator covers with radiator screws