



TUTORIAL VIDEO



( Scan with your phone )  
(Scanner avec votre Mobile)

**AX1574**  
Radiator Guards  
Sherco 250/300 2T

4 PM03-02-014 - Spacers 122mm  
1 PM03-01-009 - Spacer 54mm  
10 NE01-01-001 - Tbhc 6x16mm

**1)** Fix the 122mm spacers on the small plate, use OEM screws to fix on the frame, circled hole on top **2)** Use radiator flexibility to put back the air deflector **3)** fixe the 54mm spacer on the protection and move the cables to make the protection going against the center frame **4)** Fix the protection **5)** Repeat the same process for left side **6)** Use OEM screw

**1)** Fixer les entretoises 122mm puis l'ensemble sur le cadre avec vis d'origine, le petit trou vers le haut **2)** Utiliser la flexibilité du radiateur pour glisser le déflecteur **3)** Fixer l'entretoise 54mm puis placer le grand côté en bougeant les cables **4)** Fixer la protection **5)** Répéter le process pour côté gauche **6)** Utiliser la vis d'origine

