



- 2 NE01-03-001 - M6 Washers
- 4 NE01-04-003 - Em6f
- 5 NE10-01-004 - Alloy spacers
- 1 NE01-06-010 - Th 6x15mm
- 2 NE01-06-004 - Th 6x60mm
- 2 NE01-02-009 - Tfhc 6x55mm



AX1637

Red Chain guide

HONDA

CRF250R/RX CRF450R/RX

1



Place the 5 alloy spacers
Placer les 5 entretoises alu

2



Put the first part in place
Positionner la première partie

3



Encase both parts
Emboîter les deux parties

4



Place the TH 6x60mm + TH 6x15mm

5



Place the Tfhc 6x55mm

6



Place em6f + M6 washers and tight it
Placer écrous et rondelles puis serrer