



- 2 NE01-03-001 - M6 Washers
- 4 NE01-04-003 - Em6f
- 5 NE10-01-004 - Alloy spacers
- 1 NE01-06-010 - Th 6x15mm
- 2 NE01-06-004 - Th 6x60mm
- 2 NE01-02-017 - Tfhc 6x60mm

**AX1654**

Blue Chain guide

TM Racing

125/144/250/300



1

**Place de 5 alloy spacers**  
Placer les 5 entretoises alu



2

**Put the first part in place**  
Mettre la première partie en place



3

**Encase both parts**  
Emboiter les deux parties



4

**Place the Th 6x60mm + Th 6x15mm**  
Placer les Th6x60mm + Th 6x15mm



5

**Place the Tfhc 6x60mm**  
Placer les Tfhc 6x60mm



6

**Tight everything with M6 Washers + Em6f**  
Tout serrer avec les R.M6 + Em6f