



- 2 NE01-02-001 - TFHC 6x16mm
- 3 NE01-02-003 - TFHC 6x25mm
- 4 NE01-02-004 - TFHC 6x30mm
- 1 NE01-06-028 - TH 6x35mm
- 2 NE01-11-001 - Special screw
- 8 NE01-03-001 - M6 Washers
- 1 NE01-03-006 - M6 LARGE Waher
- 8 NE01-04-003 - EM6F
- 1 PM01-10-019 - 30mm thick block
- 1 PM01-04-261 - 20mm thick block
- 1 PM01-04-262 - 20mm thick block
- 1 PM01-06-075 - 8mm thick plate
- 1 NE04-01-239 - Black sticker



The paper instructions may be limitless,
a tutorial video is available to help

AX1696
KTM | HVA | GASGAS
690 / 701 / 700
Adventure Skid Plate



A skid plate is made to protect the vital components of your bike and does not have a « life warranty ». However, production default may happen and we cover it during the first year of use.
In case of premature breakage, please write to : contact@axpracing.com