



# AX1739

## Front A-arm guards

### Polaris Sportsman 570

# Assembling instructions

### What's in the box ?

- 1 PM01-10-025 - HDPE 30mm brackets - left
- 1 PM01-10-026 - HDPE 30mm brackets - right
- 2 PM01-10-027 - HDPE 30mm brackets
- 6 NE01-07-008 - TRCC 6x55mm
- 6 NE01-04-003 - EM6F bolts
- 6 NE01-03-001 - M6 washers



Watch the tutorial video online to help you.

Scannez le QR code pour regarder la vidéo de montage.



---

Approximate time of assembly: 15 minutes.

Front A-arm guards are made to protect the vital components of your UTV and do not have a « life warranty ». However, production default may happen and we cover it during the first year of use.

In case of premature breakage, please write to [contact@axpracing.com](mailto:contact@axpracing.com)

Place all the screws and bolts in the correct spot and watch the tutorial video online to mount the guard on your vehicle.

