



# AX1740

## Rear A-arm guards

### Polaris Sportsman 570

# Assembling instructions

## What's in the box ?

- 4 PM01-04-281 - HDPE 20mm brackets
- 2 PM01-05-025 - HDPE 15mm rectangles
- 2 PM01-06-081 - HDPE 8mm rectangles
- 4 NE01-07-007 - TRCC 6x70mm
- 8 NE01-03-001 - M6 washers
- 8 NE01-04-003 - EM6F bolts
- 4 NE01-07-005 - TRCC 6x35mm



Watch the tutorial video online to help you.

Scannez le QR code pour regarder la vidéo de montage.



---

Approximate time of assembly: 15 minutes.

Rear A-arm guards are made to protect the vital components of your UTV and do not have a « life warranty ». However, production default may happen and we cover it during the first year of use.

In case of premature breakage, please write to [contact@axpracing.com](mailto:contact@axpracing.com)

Place all the screws and bolts in the correct spot and watch the tutorial video online to mount the guard on your vehicle.

