



- 6 NE01-02-005 Tfhc 6x35mm
- 8 NE01-04-003 Em6f
- 8 NE01-03-001 Alu ring M6
- 2 NE01-03-006 Alu ring M6 Large
- 2 NE01-06-026 Th 6x25mm
- 2 NE01-02-003 Tfhc 6x25mm
- 2 PM01-04-147 Rear plastic fixation
- 1 PM01-06-017 N°2



AX1421
Xtreme Skid plate
 HVA TE250/300



PM01-06-017 + PM01-04-147
 Tfhc 6x25 + Tfhc 6x35 + Ring M6 +
 Em6f

Clipser sur l'arrière du cadre
Clip it on the rear frame

Fixer l'avant du sabot dans le cadre
Fit the front of the skid plate in the frame



- 6 NE01-02-005 Tfhc 6x35mm
- 8 NE01-04-003 Em6f
- 8 NE01-03-001 Alu ring M6
- 2 NE01-03-006 Alu ring M6 Large
- 2 NE01-06-026 Th 6x25mm
- 2 NE01-02-003 Tfhc 6x25mm
- 2 PM01-04-147 Rear plastic fixation
- 1 PM01-06-017 N°2



AX1421
Xtreme Skid plate
 HVA TE250/300



PM01-06-017 + PM01-04-147
 Tfhc 6x25 + Tfhc 6x35 + Ring M6 +
 Em6f

Clipser sur l'arrière du cadre
Clip it on the rear frame

Fixer l'avant du sabot dans le cadre
Fit the front of the skid plate in the frame