



AX1574
Radiator Guards
Sherco 250/300 2T

4 PM03-02-014 - Spacers 122mm
1 PM03-01-009 - Spacer 54mm
10 NE01-01-001 - Tbhc 6x16mm



TUTORIAL VIDEO



(Scan with your phone)
(Scanner avec votre Mobile)

1) Fix the 122mm spacers on the small plate, use OEM screws to fix on the frame, circled hole on top **2)** Use radiator flexibility to put back the air deflector **3)** fixe the 54mm spacer on the protection and move the cables to make the protection going against the center frame **4)** Fix the protection **5)** Repeat the same process for left side **6)** Use OEM screw

1) Fixer les entretoises 122mm puis l'ensemble sur le cadre avec vis d'origine, le petit trou vers le haut **2)** Utiliser la flexibilité du radiateur pour glisser le déflecteur **3)** Fixer l'entretoise 54mm puis placer le grand côté en bougeant les cables **4)** Fixer la protection **5)** Répéter le process pour côté gauche **6)** Utiliser la vis d'origine

