



- 2 NE01-03-001 - M6 Washers
- 4 NE01-04-003 - Em6f
- 5 NE10-01-004 - Alloy spacers
- 1 NE01-06-010 - Th 6x15mm
- 2 NE01-06-004 - Th 6x60mm
- 2 NE01-02-009 - Tfhc 6x55mm

AX1632
Chain guide
HONDA
CRF250R/RX CRF450R/RX



1

Place the 5 alloy spacers
Placer les 5 entretoises alu

2

Put the first part in place
Mettre la première partie en place

3

Encase both parts
Encastrer les deux parties

4

Place the Th 6x60mm + Th 6x15mm
Placer les Th 6x60mm + Th 6x15mm

5

Place the Tfhc 6x55mm
Placer les Tfhc 6x55mm

6

Place the em6f + M6 Washers and tight it
Placer les em6f + M6 washers et serrer