



- 2 NE01-03-001 - M6 Washers
- 4 NE01-04-003 - Em6f
- 5 NE10-01-004 - Alloy spacers
- 1 NE01-06-010 - Th 6x15mm
- 2 NE01-06-004 - Th 6x60mm
- 2 NE01-02-017 - Tfhc 6x60mm



**AX1633**  
Chain guide  
**TM Racing**  
125/144/250/300



1  
Place the 5 alloy spacers  
*Placer les 5 entretoises alu*



2  
Put the first part in place  
*Mettre la première partie en place*



3  
Encase both parts  
*Encastrer les deux parties*



4  
Place the Th 6x60mm + Th 6x15mm  
*Placer les Th 6x60mm + Th 6x15mm*



5  
Place the Tfhc 6x60mm  
*Placer les Tfhc 6x60mm*



6  
Place the em6f + M6 Washers and tight it  
*Placer les em6f + M6 washers et serrer*