



# AX1733

## Radiator braces

### Sherco SEF300

#### What's in the box ?

9 NE01-01-001 - TBHC 6x16mm screws  
1 NE01-02-001 - TFHC 6x16mm screws  
2 NE01-01-007 - TBHC 6x30mm screws  
2 NE01-03-006 - M6 large washers  
2 PM03-02-014 - Black spacers 122mm  
2 PM03-02-032 - Black spacers 100mm  
1 PM03-01-022 - Alloy spacer 49mm



For better durability, you can use Loctite 271 on all the screws.

The paper instructions may be limitless, scan the QR code to watch the tutorial video online.




## Assembling instructions

Approximate time of assembly: 15 minutes.

Radiator guards are made to protect the vital components of your bike and does not have a « life warranty ». If you notice a defect on your radiator guards at reception, please write to [contact@axpracing.com](mailto:contact@axpracing.com)

#### Follow the steps




1

Fix the 122mm black spacers in the top holes and the 100mm in the bottom ones with the TBHC 6x16mm screws.




2

Fix the alloy spacer on the right guard using a TBHC 6x16mm screw.




3

Remove the plastics, the tank and the two OEM screws. Then place the front side and use the OEM screws to fix it.




4

Put the rear side in place. Make sure to pass the guard under the wires.



5

Place 2 TBHC 6x16mm screws in the top and bottom holes to fix the 2 parts together without tightening.




6

Cut the bottom of the air deflectors for a perfect fitment with the guards. You must cut the closest parts from the frame.




7

Clip the air deflector back in place.




8

Place the front guard on the other side, and fix it with the two OEM screws.




9

Tighten the screws and put the air deflector back in place.




10

Remove the electronic device.




11

Place the rear part using the TFHC 6x16mm screw in the right hole and two TBHC 6x16mm screws in the top and bottom holes, without tightening.



12

Tighten the TFHC first.




13

Then tighten the two other screws.



14

Put the electronic device back in place.



15

Tighten the screws on the other side.



16

Put the tank back and don't forget to tighten the screw. Then, put the plastics back in place and use one TBHC 6x30mm screw + M6 washer on each side to fix it.

**You're all ready to ride !**