

AX1744

Xtrem skid plate

Yamaha - YZ250F

What's in the box?

2 NE01-04-002 - Clamped bolts

1 NE10-01-004 - Alloy spacers

4 NE01-03-001 - M6 washers

4 NE01-04-003 - EM6F bolts

1 NE01-06-003 - TH 6x30 screw

2 NE01-02-002 - TFHC 6x20 screws

2 NE01-02-005 - TFHC 6x35 screws

2 NE01-11-001 - Special screws

1 PM02-07-028 - Front steel fixation

1 PM01-04-248 - HDPE rear fixation 20mm

1 PM01-06-076 -Linkage protection

1 NE04-01-250 - Sticker



The paper instructions may be limitless, a tutorial video is available online to help you.



Assembling instructions

Approximate time of assembly: 15 minutes.


A skid plate is made to protect the vital components of your bike and does not have a « life warranty ». However, production default may happen and we cover it during the first year of use.

In case of premature breakage, please write to contact@axpracing.com


Follow the steps!




Place the alloy spacers in the middle hole of the rear fixation.




Fix the rear fixation on the rear part of the plate using the TFHC 6x35 screws + 2 washers + 2 bolts and tighten.




Make sure to place the largest machined side towards the end of the plate.




Place the clamped bolts on the steel part. Make sure to align them to the holes



Place the alloy spacer in the back of the plate.




Place the steel part inside the frame. The round sides of the clamped bolts must face upwards.



Place the plate using the TH 6x30mm screw on the rear.



Tighten the screw.




Place the 2 special screws on the front. Use the bigger hole to maintain the front fixation.




Tighten the screws.



Push the plate down and place the smaller plate under the linkage.



Place 2 TFHC 6x20mm screws + washers and bolts to fix the plates together.



Tighten the screws.

You're all ready to ride!