



AX1746

Adventure skid plate

Kove 450 Rally

What's in the box ?

- 1 PM01-04-290 - Front fixation 20mm
- 1 PM01-05-028 - Middle support 15mm
- 2 PM01-04-289 - Rear fixations 20mm
- 1 PM01-06-088 - Linkage guard 8mm
- 1 NE04-01-277 - Sticker
- 8 NE01-02-003 - TFHC 6x25mm screws
- 14 NE01-04-003 - EM6F bolts
- 14 NE01-03-001 - M6 washers
- 4 NE01-02-002 - TFHC 6x20mm screws
- 2 NE01-02-004 - TFHC 6x30mm screws
- 1 NE01-06-001 - TH 6x45mm screw
- 1 NE10-01-004 - Spacer
- 4 NE01-06-003 - TH 6x30 screws
- 4 NE01-03-006 - M6 large washers
- 2 NE13-01-001 - Foam



The paper instructions may be limitless, scan the QR code to watch the tutorial video online.

Assembling instructions

Approximate time of assembly: 30 minutes.

A skid plate is made to protect the vital components of your bike and does not have a « life warranty ». However, production default may happen and we cover it during the first year of use.


In case of premature breakage, please write to contact@axpracing.com

Follow the steps



1

Cut the foam pads and stick them on each side of the plate to protect the tank.



2



3

Place the front fixation using 2 TFHC 6x25mm screws + M6 washers and bolts.




4

Tighten and make sure to place the longer machined part on the left.



5

Place the middle support using 2 TFHC 6x30mm screws + M6 washers and bolts then tighten.



6




7

Place the rear fixations and use in the top holes 1 TFHC 6x20mm screw + M6 washer and bolt on each side.




8

Use 6 TFHC 6x25mm screws + M6 washers and bolts, then tighten. Make sure to put the screws in the small machined holes.



9

Fix the linkage guard using 2 TFHC 6x20mm screws + M6 washers and bolts.




10

Place the skid plate under the frame. The machined faces must be perfectly aligned with the holes on the frame.



12

Place 4 TH 6x30mm screws + large M6 washers under the plate without tightening.



13

Place the spacer in the front hole.



14

Place the TH 6x45mm screw to fix the front part of the plate.



15

Tighten the 4 rear screws.



16

Tighten the front screw.

You're all ready to ride !