



AX1764

Skid plate

Triumph TF250X

Assembling instructions

What's in the box ?

- 1 PM01-04-287 - Front fixation
- 2 NE01-04-002 - Clamped bolts
- 1 PM01-10-031 - Rear block 30mm
- 1 PM03-04-134 - Rear fixation aluminum
- 2 NE01-02-002 - TFHC 6x20mm screws
- 4 NE01-04-003 - EM6F bolts
- 4 NE01-03-001 - M6 washers
- 1 NE01-02-004 - TFHC 6x30mm screws
- 1 NE01-02-003 - TFHC 6x25mm screws
- 2 NE01-03-006 - M6 large washers
- 2 NE01-01-009 - TBHC 6x20mm screws
- 2 NE01-11-001 - THF 6x25mm screws
- 1 NE04-01-272 - Sticker



The paper instructions may be limitless, scan the QR code to watch the tutorial video online.

This tutorial shows a different skid plate but the mounting is the same.



Approximate time of assembly: 15 minutes.


A skid plate is made to protect the vital components of your bike and does not have a « life warranty ». However, production default may happen and we cover it during the first year of use. In case of premature breakage, please write to contact@axpracing.com

Follow the steps !



1

Place the clamped bolts in the front fixation.




2

Put the front fixation inside of the frame. For an easy assembly, you can slide it on the side.




Note: this is not the Triumph frame but fitment is the same.




3

Place the aluminum fixation on the rear of the plate using 2 TFHC 6x20mm screws + washers and bolts.




4

Place the rear block on using one TFHC 6x30mm and one TFHC 6x25mm screws + washers and bolts, and tighten.




5

Put the skid plate in position on the frame.




6

Fix the skid plate using a TBHC 6x20mm screw + large washer on each side.




7

Place the THF 6x25mm screws on the front without tightening.



8

Tighten the rear screws.



9

Tighten the front screws.

You're all ready to ride !